

*Thank you for your purchase of The CleanCut Convertible™. CleanCut has prepared these standard care and use instructions for The CleanCut Convertible™. Please feel free to contact the installer of this product or CleanCut, with any questions you may have.*

**Instructions Prior to First Use**

- Do not use the tub, remove the center insert, or apply any weight to The CleanCut Convertible™ for two (2) days after installation is completed to allow for The Convertible's adhesive to completely dry and cure.
- Prior to first use, please inspect the bead of adhesive around the perimeter of The Convertible to ensure that a continuous adhesive bead has been applied and that there are no cracks or areas where the adhesive is absent. Conduct a similar inspection of the perimeter adhesive every six (6) months thereafter.
- Prior to first use, please clean and rinse the bathtub to rid the area of any dust and/or particulates that may remain after installation. Similarly, please remove the center insert of Convertible™ and wipe the seals on the bottom of the center insert removing any potential dirt or particulates.

**Cleaning Instructions**

- It is recommended that the unit be cleaned regularly with a gentle household cleaning agent. The center insert should also be removed and all areas, including the seals, should be cleaned regularly. Do not use harsh cleaners or abrasive tools to clean The Convertible™.

**General Use Instructions**

- For use as a full bath, apply the center insert and align the holes on the left and right side of the insert with the corresponding holes on The Convertible frame. Press downward on the center insert to allow on both sides to ensure the insert is fully compressed into position. Insert the rosette knobs on each side of the center insert and tighten the rosette knobs completely.
- For use as a step in shower, unscrew and remove the two rosette knobs. Once unscrewed, lift and remove the center insert portion.
- When not in use, store the center insert with the seals facing up and not compressed.
- Do not use the unit as a grab-bar or assistive device.
- As with any bathtub, children should not be left unattended in the bathtub.